


FIRMWARE UPGRADE

- The latest Digifly software may be installed using the optional PC serial or USB cable.
- The optional PC serial or Digifly USB cable is connected to the middle socket on the base of the Digifly instrument.
- When upgrading from Digifly instrument firmware version to a new version all settings will be restored to the factory default.




UPGRADE PROCESS

- 1) Make sure the battery on your Digifly instrument is fully charged.
- 2) Turn off your Digifly instrument and plug the Digifly PC serial or USB cable in to the middle socket on the base of the Digifly instrument.
- 3) Keeping the **MENU** key pressed, press the **ON-OFF** key and wait a long “beep” acoustic confirmation. Note that the screen will not come on. **Note** : if the instrument does not emit any sound : disconnect the cable , repeat again from the beginning this step 3 and connect again the cable at the end of step 4.
- 4) Now release the **ON-OFF** key and then the **MENU** key.
- 5) From your PC, run the “Upgrade_xx_x_your_model.exe” program.

- 6) Press the Start Button.

- 7) Make sure you have only one version of the “Upgrade_xx_x_your_model.exe” programme open at a time.

- 8) When the “Upgrade_xx_x_your_model.exe” tools software is operating you will see the progress of the software.



- 9) The upgrade takes about 5 minutes, on completion the PC will confirm with a long “beep”.

- 10) Press the **ON-OFF** key and disconnect the PC cable.

Note: When you restart your Digifly instrument the version number of the new software you have just installed is briefly shown on the start up screen.

It is suggested that you upload the new “**help setup**” file in order to obtain information on any of the new parameters that have been installed with the upgrade. Use the function “**Upload Help**” from within the latest version of the Digifly Vtools software.